


Leyland 154 Diesel Tractor - Electrical Wiring Diagram

WIRING DIAGRAM (DIESEL MODELS)



E2396A

KEY TO WIRING DIAGRAM - (DIESEL MODELS)

<i>No.</i>	<i>Description</i>	<i>No.</i>	<i>Description</i>
1.	Dynamo	23.	Horn
2.	Control box	24.	Horn push
3.	Battery	27.	Heater plug warning light
5.	Starter motor	30.	Ballast resistor
6.	Lighting switch	32.	Heater plug relay
8.	Right-hand headlamp	40.	Heater plugs
9.	Left-hand headlamp	48.	Ammeter
11.	Right-hand side and tail lamp	75.	Safety start switch
12.	Left-hand side and tail lamp	79.	Trailer socket and plug
15.	Number plate illumination lamp	157.	Plough lamp

CABLE COLOUR CODE

B.	Black	G.	Green	Y.	Yellow
U.	Blue	R.	Red		
N.	Brown	W.	White		

Where a cable has two colour code letters the first denotes the main colour and the second denotes the tracer colour