

KEY TO WIRING DIAGRAM

<i>No.</i>	<i>Description</i>	<i>No.</i>	<i>Description</i>
1.	Dynamo	26.	Direction indicator switch
2.	Control box	27.	Direction indicator warning lamp
3.	Battery	28.	Right-hand flasher lamp
4.	Starter solenoid	29.	Left-hand flasher lamp
5.	Starter motor	34.	Fuel gauge
6.	Lighting switch	35.	Fuel gauge tank unit
8.	Right-hand headlamp	38.	Starter switch
9.	Left-hand headlamp	46.	Water temperature gauge
10.	Main-beam warning lamp	47.	Water temperature transmitter
11.	Right-hand side lamp	64.	Bi-metal instrument voltage stabilizer
12.	Left-hand side lamp	67.	Line fuse (10 amps)
14.	Panel lamps	75.	Safety start switch
15.	Number-plate lamp	79.	Trailer socket
16.	Right-hand tail lamp	146.	Battery condition indicator
17.	Left-hand tail lamp	155.	Air filter switch
23.	Horn	156.	Air filter warning lamp
24.	Horn-push	157.	Plough lamp
25.	Flasher unit	158.	Printed circuit instrument panel

CABLE COLOUR CODE

B.	Black	G.	Green	R.	Red
U.	Blue	LG.	Light Green	W.	White
N.	Brown	P.	Purple	Y.	Yellow

When a cable has two colour code letters the first denotes the main colour and the second denotes the tracer colour